Quick Start Guide for Presto Gigabit Ethernet Pro ExpressCard/34

INSTALLATION STEPS FOR MAC USERS

The following section covers configuration and use of the Presto Gigabit Ethernet Pro ExpressCard/34 card in a MacBook Pro. If you are using the Presto card in a Windows notebook, skip to INSTALLATION STEPS FOR WINDOWS USERS.

Driver Information—OS X

The drivers that enable the Presto Gigabit Ethernet Pro ExpressCard/34 card to work in your computer are installed as part of OS X; the Presto card is ready to use when you insert the card into your computer.

System Configuration Steps—Mac Users

Listed below are the basic steps necessary to add the Presto Gigabit Ethernet Pro ExpressCard/34 for use as one of your computer's Ethernet network ports.

- 1. Plug in a network-connected twisted-pair Ethernet cable into the Presto Gigabit Ethernet Pro ExpressCard/34 before inserting the card into your computer.
- 2. Insert the Presto card into your computer's ExpressCard slot and then start up your computer.
- **3.** After your computer has finished booting, launch the System Preferences application, and then click Network.
- **4.** If it is not already selected, click on the Presto Gigabit Ethernet Pro ExpressCard/34 (identified as a *PCI Ethernet slot ExpressCard*) in the left panel, and then configure the settings, if necessary. If your computer was connected to a network using built-in Ethernet, you should not have to enter new settings.
- **5.** After you accepted the existing settings, edited them, or created new ones, click the Apply button.
- 6. Close System Preferences; if you used existing settings, your installation is complete. For additional information on configuring settings, refer to Mac Help (Help > Mac Help from the Finder) and www.info.apple.com; type "network, Ethernet" and "combining Ethernet ports" to display various articles.

INSTALLATION STEPS FOR WINDOWS USERS

The following section covers configuration and use of the Presto Gigabit Ethernet Pro ExpressCard/34 card in a Windows laptop computer.

Driver Information—Windows 8

The drivers that enable the Presto Gigabit Ethernet Pro ExpressCard/34 card to work in your computer are installed as part of Windows 8; the Presto card is ready to use when you insert the card into your computer.

Windows 7—Software Download/Installation Steps

- 1. Insert the Presto card into your computer's ExpressCard slot and then start up your computer.
- 2. Log onto the Internet and go to www.sonnettech.com/ support, and then click the Online Support Knowledgebase link.
- **3.** Click the Computer Cards link, and then click the ExpressCard/34 Cards link.
- **4.** Locate and click the Presto Gigabit Ethernet Pro ExpressCard/34 link. Note: *Do not click the Presto Gigabit Ethernet Pro ExpressCard/34 (Discontinued) link.*
- **5.** Click the Presto Gigabit Ethernet Pro ExpressCard/34 Driver (Windows) link, and then click Download Now; a new window or tab will appear.
- 6. Locate and click the file download link for the software appropriate for the OS software running your computer (32 for 32-bit operating systems, x64 for 64-bit versions).
- 7. When the *Broadcom License Agreement* window appears, scroll to the bottom of the page and then click Accept.
- **8.** When asked whether you want to open or save the file, click Save. When the message stating the download completed appears, click Open; a new window will appear.
- **9.** Select the win_b57_32 (or win_b57_x64) file folder, and then click the "Extract all files" button toward the top of the window.
- **10.** When the *Extract Compressed (Zipped) Folders* window appears, accept the default extraction location or choose a new one, and then click Extract; the file will be extracted.
- 11. From the Start menu, right-click Computer and then select Manage; the *Computer Management* window will appear.

(continued)

Quick Start Guide for Presto Gigabit Ethernet Pro ExpressCard/34

Windows 7—Software Download/Installation Steps (continued)

- 12. In the window's left panel, locate and click Device Manager. In the middle panel, locate and double-click the Ethernet Controller item listed in the "Other devices" category; an Ethernet Controller Properties window will appear.
- 13. Click the Update Driver button; an Update Driver Software window will appear.
- 14. Click "Browse my computer for driver", and then click Browse. Locate and select the win_b57_32 (or win_b57_x64) folder you downloaded, and then click OK.
- 15. Back in the Update Driver Software window, click Next; the driver is installed. When a message appears stating the software installation is complete, click Close; the card is ready for use.

Windows Vista—Software Download/Installation Steps

- 1. Insert the Presto card into your computer's ExpressCard slot and then start up your computer.
- 2. During startup, a Found New Hardware window will appear; click "Don't show this message again for this device". If you haven't disabled User Account Control (UAC), a UAC window will appear; click Continue.
- 3. Log onto the Internet and go to www.sonnettech.com/ support, and then click the Online Support Knowledgebase link.
- 4. Click the Computer Cards link, and then click the ExpressCard/34 Cards link.
- 5. Locate and click the Presto Gigabit Ethernet Pro ExpressCard/34 link. Note: Do not click the Presto Gigabit Ethernet Pro ExpressCard/34 (Discontinued) link.
- 6. Click the Presto Gigabit Ethernet Pro ExpressCard/34 Driver (Windows) link, and then click Download Now; a new window or tab will open.
- 7. Locate and click the file download link for the software appropriate for the OS software running your computer (32 for 32-bit operating systems, x64 for 64-bit versions).
- 8. When the Broadcom License Agreement window appears, scroll to the bottom of the page and then click Accept.
- 9. When asked whether you want to open or save the file, click Save. When the message stating the download completed appears, click Open; a new window will appear.
- 10. Select the win b57 32 (or win b57 x64) file folder, and then click the "Extract all files" button toward the top of the window.

- 11. When the Extract Compressed (Zipped) Folders window appears, accept the default extraction location or choose a new one, and then click Extract; the file will be extracted.
- 12. From the Start menu, right-click Computer and then select Manage; the Computer Management window will appear.
- 13. In the window's left panel, locate and click Device Manager. In the middle panel, locate and double-click the Ethernet Controller item listed in the "Other devices" category; an Ethernet Controller Properties window will appear.
- 14. Click the Reinstall Driver button; an Update Driver Software window will appear.
- 15. Click "Browse my computer for driver", and then click Browse. Locate and select the win_b57_32 (or win_b57_x64) folder you downloaded, and then click OK.
- 16. Back in the Update Driver Software window, click Next; the driver is installed. When a message appears stating the software installation is complete, click Close; the card is ready for use.

System Configuration Steps—Windows Users

Listed below are the basic steps necessary to add the Presto Gigabit Ethernet Pro ExpressCard/34 for use as one of your computer's network connections.

- 1. Plug in one end of an Ethernet cable to the Presto adapter's Ethernet port. Connect the other end to a cable or DSL modem, or a network.
- 2. Connect either the included USB 3.0 cable or another USB 3.0 cable between the Presto adapter and a USB port on your computer.
- 3. With your computer turned on, depending on your setup, Windows may configure itself automatically to work with the Presto adapter. Launch a Web browser and browse a Website to verify.
- 4. If your system did not configure itself, access the Network and Sharing Center to make necessary changes.



Remember to register your product online at http://registration. sonnettech.com to be informed of future upgrades and product releases. Software updates and links are available from the Sonnet web site at www.sonnettech.com. • Online support form available www.sonnettech.com at http://supportform.sonnettech.com.

- Sonnet Technologies Customer Service hours are Mon.-Fri., 7 a.m.-4 p.m. Pacific Time
- Customer Service Phone: 1-949-472-2772
- E-mail: support@sonnettech.com
- Sonnet Technologies, Inc. Irvine, California 92618 USA
- Tel: 1-949-587-3500

©2013 Sonnet Technologies, All rights reserved. Sonnet, the Sonnet logotype, Simply Fast, the Simply Fast logotype, and Presto are trademarks of Sonnet Technologies, Inc. Mac. the Mac logo, MacBook Pro, and OS X are trademarks of Apple Inc., registered in the United States and other countries. Other product names are trademarks of their respective owners. Product specifications subject to change without notice. Printed in the USA. QS-GE1000LAB-E34-E.A-102413